

ASSEMBLY INSTRUCTIONS




PARTS AND FITTING PACKAGING DETAIL





BOX #3
D. SIDE RAILS
E. CENTER SUPPORT
F. SUPPORT LEG

2 PCS
1 PC
3 PCS




FULLY ASSEMBLED



HARDWARE KIT PACKED IN BOX #2				
1	THREADED BOLT (8x60mm)		8 PCS	
2	ARC WASHER (2x14x26mm)	0	8 PCS	
3	LOCK WASHER (M10)	Ø	8 PCS	
4	HEX NUT (M8)	©	8 PCS	
5	WRENCH	S	1 PC	
6	WOOD SCREW (4x35mm)	(a)	2 PCS	
7	WOOD SCREW (4x25mm)		9 PCS	
8	ALLEN KEY		1 PC	


STEP 1




ASSEMBLY INSTRUCTIONS











•IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5 & 6 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT. •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4

ASSEMBLY INSTRUCTIONS










STEP 6




INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



MAINTENANCE INSTRUCTIONS:

- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

ASSEMBLY INSTRUCTIONS





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1SET *WOOD SCREW (4x35mm) :2PCS E. CENTER SUPPORT : 1PC *WOOD SCREW (4x25mm) :9PCS

F. SUPPORT LEG : 3PCS

STEP #1:

USE ALLEN KEY (8) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.




NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION.


ASSEMBLY INSTRUCTIONS




PARTS AND FITTING PACKAGING DETAIL









BOX #3	
D. SIDE RAILS	2 PCS
E. CENTER SUPPORT	1 PC
F. SUPPORT LEG	3 PCS




FULLY ASSEMBLED





00:30







ASSEMBLY INSTRUCTIONS













STOP


•IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5 & 6 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.


•IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4

ASSEMBLY INSTRUCTIONS










STEP 6




INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



MAINTENANCE INSTRUCTIONS:

- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

ASSEMBLY INSTRUCTIONS APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT



AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1SET *WOOD SCREW (4x35mm) :2PCS E. CENTER SUPPORT : 1PC *WOOD SCREW (4x25mm) :9PCS

F. SUPPORT LEG : 3PCS

STEP #1:

USE ALLEN KEY (8) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.




NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION.


ASSEMBLY INSTRUCTIONS



PARTS AND FITTING PACKAGING DETAIL




FULLY ASSEMBLED



Not provided

HARDWARE KIT PACKED IN BOX #2				
1	THREADED BOLT (8x60mm)		8 PCS	
2	ARC WASHER (2x14x26mm)	0	8 PCS	
3	LOCK WASHER (M10)	O	8 PCS	
4	HEX NUT (M8)		8 PCS	
5	WRENCH	\(\sigma_{\text{s}} \)	1 PC	
6	WOOD SCREW (4x35mm)	© James Control	2 PCS	
7	WOOD SCREW (4x25mm)	9	9 PCS	
8	ALLEN BOLT (6x60mm)		12 PCS	
9	LOCK WASHER (M9)	Ø	12 PCS	
10	FLAT WASHER (M6)	0	12 PCS	
11	ALLEN KEY		1 PC	


STEP 1




ASSEMBLY INSTRUCTIONS












STOP


•IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
•IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4

ASSEMBLY INSTRUCTIONS











STEP 6



ASSEMBLY INSTRUCTIONS






INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (G).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



MAINTENANCE INSTRUCTIONS:

- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

ASSEMBLY INSTRUCTIONS





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.


PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.

THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL :1SET *WOOD SCREW (4x35mm) :2PCS F. CENTER SUPPORT : 1PC *WOOD SCREW (4x25mm) :9PCS G. SUPPORT LEG : 3PCS *ALLEN BOLT (6x60mm) :12PCS E. SPACER : 2PCS *LOCK WASHER (M9) :12PCS *FLAT WASHER (M6) :12PCS

STEP #1:

USE ALLEN KEY (11) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.



NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION.